Alarm Lock: Essential add-ons and extras

Strikes for model 11A:

Model 210K

• Strike for single or double inswinging door(s) (not included with 11A)

Model K24A

• Strike for single outswinging door (included with 11A)

Model K28

• Strike for double outswinging doors (not included with 11A)

Rim cylinder

Model CER

• Required for interior arming/disarming of models 11A, 80, 250, 260, 700, 710 & 715. Includes two keys (KA or KD)

Mortise cylinder

Model CEM

• Used with the Pilfergard models PG10 and PG21/E to arm and disarm the alarm circuit. Includes two keys (KA or KD)

Cylinder finger pull

Model 711

• An inexpensive door pull for use when outside key only access is required.

Outside access door pull

Model 707

• For access from building exteriors. Installed on the outside of the door and linked to the lock. After deadbolt is retracted by outside key, a slight pull will release the deadlatch and open the door. 8" x 1 1/2". (For use with all models except Model 11A).





Model PP100

 For use with all PG10, PG21/E, PG30, 250, 700, 80, 260, 710 and 715 models. The PP100 conserves the battery which automatically takes over as the power source to sound the alarm in the event of a

power failure or intentional cut-off. A built-in circuit breaker with push-button reset eliminates troublesome fuse replacements. Includes a cam lock cylinder and 6' of armored cable adequate to provide a door loop at the hingedside of the door. Can be used with all 6V and 9V models.

Double door holder

Model 44

• The Double Door Holder secures the inactive door to the frame while the

active door is closed. Releasing the active door automatically allows both doors to swing freely. Reversible, right or left hand doors. Cast aluminum 8 1/2" long, 3" wide and 2 1/2" high.

Armored door loop

Model 271

• For use with electrified locks. An easy means for bringing electric current from the hinge side of a door frame to the

door. 18" flexible armored cable. End brackets are deep drawn anodized aluminum to conceal wire connections.

Single door strike

Models 730 & 725

- Model 730 supplied with models 250, 700 and 80
- Model 730M supplied with models 260 and 710 and 80



• Model 725 supplied with model 715

Double door strike

Models 732 & 735

- Model 732 for use with models 250, 700 and 80.
- Model 732M for use with models 260 and 710.
- Model 735 for use with model 715. (Not Shown)

Cable energy switch

Model 261

- Transfers current to other side of the door.
- For use with models 250, 100 and 11A











