

# MAIL SLOT SLEEVE NO. C601

FOR USE ON EXTERIOR DOOR OF HOMES, CONDOMINIUMS, APARTMENTS AND OFFICES. COVERS ROUGH EDGES OF CUTOUT ON SOLID OR HOLLOW DOORS AND PREVENTS MAIL FROM FALLING INTO HOLLOW CORE DOORS.

Fits IVES mail slots nos. 620, 621, 622 or standard mail slots requiring an  $11\frac{1}{2}$ " x  $2\frac{11}{16}$ " cutout.

### INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Phillips screwdriver.

#### For Existing Mail Slot Installations:

- 1. Remove mail slot plate from inside door.
- 2. Insert sleeve through door cutout. Secure with two screws provided.
- 3. Replace and secure front plate over sleeve.

## For New Mail Slot Installations:

- 1. Follow mail slot installation instructions.
- 2. Insert sleeve through door cutout and secure.
- 3. Secure front plate over sleeve.

Material - 26 gauge SUS430 stainless steel

# ASK FOR OTHER FINE DECORATIVE HARDWARE BY H.B. IVES



DOOR KNOCKERS DOOR STOPS INTERIOR LEVERS KNOBS

