



#### INSTRUCTIONS:

1. OPEN DOOR TO DESIRED POSITION.
2. PLACE STRIKE AND HOLDER AS ILLUSTRATED.  
BODY MUST ENGAGE STRIKE SQUARELY.
3. LOCATE MOUNTING HOLES.
4. PREPARE MOUNTING HOLES AS NECESSARY.
5. INSTALL BODY AND STRIKE.

#### NOTES:

1. METAL DOORS SHOULD BE PROPERLY REINFORCED  
WITH  $\frac{3}{16}$ " (5) MINIMUM THICKNESS PLATE.

	QTY	SCREW DETAILS
BODY	3	#10 X 1" OPHSMS
	3	#10-24 X $1\frac{1}{4}$ " FPHSMS
STRIKE	2	#10 X 1" OPHSMS
	2	PLASTIC ANCHORS

**IVES**

### WS40 WALL HOLDER INSTALLATION INSTRUCTIONS

**ALLEGION**

NOTE: DIMENSIONS IN ( ) ARE IN MILLIMETERS

TEMPLATE  
NUMBER:

INST.WS40\_B

DATE:  
05-29-15