


INPUT 12-24VDC.

40mA Idle, 60mA Active, LEDs ON.

10mA Idle, 40mA Active, LEDs OFF.\*

ON TIME 1-40 sec.

| DWG. NO. |      | REVISION RECORD |  | APPD |
|----------|------|-----------------|--|------|
| REV      | DATE |                 |  |      |
|          |      |                 |  |      |
|          |      |                 |  |      |
|          |      |                 |  |      |
|          |      |                 |  |      |



With jumper in FAIL SAFE position the relay is normally ON and turns OFF when button is pressed or loss of power.

BACK VIEW

To control the LED's externally, remove the Jumpers \* and connect the middle of the three pins to the DC- screw terminal. Right for RED, Left for GREEN.

With the jumpers \* as shown the red LED's are on in stand-by and the green LED's turn on when the relay is on. To reverse the colors move the left one up and the right one down. To turn off red remove the right one, to turn off green remove the left one.

For ESSEX Piezo Button

NOTES: UNLESS OTHERWISE SPECIFIED RII86

TOLERANCES  
UNLESS OTHER-  
WISE SPECIFIED  
DIM'S IN INCHES  
.X ±.030  
.XX ±.010  
.XXX ±.005  
< ± .5\*

**ESSEX**  
**ELECTRONICS**  
**INCORPORATED**

TITLE BUTTON HOOK-UP

DR: ECHOLS 10/06

ENG:

APPD:

DWG NO:


EX-1D

SCALE:

NONE

SHEET 1 OF

| DWG. NO. |      |  | REVISION RECORD |  | APPD |
|----------|------|--|-----------------|--|------|
| REV      | DATE |  |                 |  |      |
|          |      |  |                 |  |      |
|          |      |  |                 |  |      |
|          |      |  |                 |  |      |
|          |      |  |                 |  |      |
|          |      |  |                 |  |      |
|          |      |  |                 |  |      |



NOTES: UNLESS OTHERWISE SPECIFIED

| TOLERANCES UNLESS OTHERWISE SPECIFIED DIMS IN INCHES |       |  | XE ELECTRONICS INCORPORATED      |            |
|------------------------------------------------------|-------|--|----------------------------------|------------|
| X                                                    | ±.030 |  | TITLE<br>TEMPLATE, NARROW BUTTON |            |
| .XX                                                  | ±.010 |  |                                  |            |
| .XXX                                                 | ±.005 |  |                                  |            |
| < ± .5°                                              |       |  | DR: ECHOLS 5/3/07                | DWG NO:    |
|                                                      |       |  | ENG:                             |            |
| APPD:                                                |       |  | SCALE:                           | SHEET 1 OF |
|                                                      |       |  |                                  | RTL09      |