


INSTALLATION DESCRIPTION

The Series 2050 is a 1200 pound holding force electromagnetic lock designed to retro-ft a Locknetics 350 on a single outswing door. The lock requires both installation procedures as described herein and in the separate wiring instructions included.

The illustration to the left shows a typical installation on a single outswing door.

HANDLING

Care must be taken that the lock face and armature face are kept free of dirt, rust, paint, or any other obstruction which may interfere with the lock and armature making good contact. These faces may be cleaned with a non-abrasive pad and wiped with an oil dampened cloth.

MECHANICAL INSTALLATION

Familiarize yourself with the door and frame conditions. The lock must mount rigidly to the face of the door frame header. The door mounted armature is supplied with an adjustable mounting bracket and hardware that allows it to pivot slightly to compensate for reasonable misalignment.

NOTE: If this lock is supplied with the DSM option be certain that disc magnets are present inside the armature housing.


ELECTRICAL INSTALLATION

After mechanical installation is complete the lock needs to be wired to a 12 or 24 VDC/VAC power source. Once low voltage power is supplied the unit is fully operational. All other wiring is for selected options. Refer to the separate wiring instructions included for further information.

TABLE OF CONTENTS

General Information.....	1
Bill Of Materials.....	2
Using The Template.....	3
Mounting The Armature.....	4
Mounting The Lock.....	5
Exploded Parts View.....	6
Exploded Parts Legend.....	7
Support.....	8

MODEL #2050 BILL OF MATERIALS



- (1) 2050 LOCK ASSEMBLY
- (2) ARMATURE
- (1) ARMATURE HOUSING
- (1) HARDWARE KIT
- (1) MOUNTING TEMPLATE
- (1) INSTALLATION MANUAL
- (1) WIRING MANUAL

REQUIRED TOOLS

- (1) Electric Drill
- (1) #2 Phillips Screw Driver
- (1) Soft Faced Mallet
- (1) Hammer
- (1) Center Punch
- (1) Pencil & Tape
- Drill Bits: 1/8", 17/64", 11/32", 1/2", 9/16", 21/32"


HARDWARE KIT CONTENTS (P/N 301498)

QTY.	ITEM	DESCRIPTION
6	BASEPLATE MOUNTING SCREWS	#10x1" PHILLIPS HEAD SHEET METALSCREW
6	BASEPLATE MOUNTING SCREWS	#10-24x1/2" PHILLIPS PAN HEAD MACHINE SCREW
1	ARMATURE MOUNTING SCREWS	5/16-18x2" HEX FLATHEAD MACHINE SCREW TURNED
4	ARMATURE HOUSING SCREWS	#8x1" PHILLIPS FLATHEAD SHEET METALSCREW
4	ARMATURE HOUSING SCREWS	8-32x3/8" PHILIPS FLATHEAD MACHINE SCREW
1	ARMATURE SPACER	3/8" Dx0.235"L SPACER
1	STEEL WASHER	1/4" FLATZINC WASHER
1	DOOR SPACER	5/8" Dx1-11/16" L SPACER
1	SEX NUT	5/16"-18 SEX NUT
1	HEX KEY	10/32" HEX KEY

NOTE: For further parts clarification refer to the Exploded Parts View on page 6 or consult factory.

MOUNTING CONSIDERATIONS


Inspect the door frame and determine if an angle bracket or filler plate will be required for installation. The lock will require a 2" wide header stop for a suitable mounting surface.



*See Price Book or Call DynaLock Corp.

USING THE TEMPLATE

1. Fold the template on the dotted line to form a 90 degree angle. Scoring the template with a straight edge and a screwdriver will make it fold easier.
2. With the door closed and in the latched position, from the push side, place the template against the header and door on the frame, and tape in place.
3. Transfer all hole locations to both the door and header with a center punch, then remove the template from the door.
4. Referring to the template drill two 1/8" diameter lock mounting holes (or tap for 10-24) and one 9/16" diameter wiring hole in the top of the frame, at all transferred locations. Remaining mounting holes will be drilled after the lock is first mounted and adjusted (page 6).
5. Drill the remaining transferred holes in the face of the door to accept the armature following the instructions on page 4 for your specific door type.




MOUNTING THE ARMATURE

From the three illustrations below select the one that resembles your door type and follow the instructions for drilling the Armature mounting screw hole. (See Template)


Drill four (4) 1/8" dia. holes for #8 x 1" sheet metal screws or drill and tap for #8-32 x 3/8" machine screws (See Template).

GLASS AND ALUMINUM OR HOLLOW METAL DOOR




Drill an 11/32" diameter hole through the door. From the sex nut side only enlarge the hole to 21/32" diameter.

SOLID CORE DOOR



Drill an 11/32" diameter hole through the door. From the sex nut side drill 1/2" diameter hole to 1" depth.

REINFORCED DOOR



Drill a 17/64" diameter hole and tap for 5/16-18 thread

Mount the Armature Housing to the door using four (4) #8 x 1" sheet metal screws or #8-32 x 3/8" machine screws.


Place the Armature inside the Armature Housing and secure using the proper hardware, according to the above illustrations. Firmly tighten the Armature mounting screw with a 3/16" hex wrench.

Failure to properly secure the Armature to the door could result in serious injury or possible security breach.

MOUNTING THE LOCK


1. Mounting the baseplate to the header:

Separate the baseplate from the lock housing with the hex wrench. Place the baseplate against the header with the counter sunk slots visible, and the large slot over the wire hole. Using an electric drill with a Phillips bit attach the baseplate to the header at both slotted locations with the screws provided. Tighten the screws just snug enough to allow for final adjustments.




2. Aligning the lock and armature

Close and latch the door. Temporarily mount the lock to the baseplate and verify the lock face and the armature are making full contact for the entire length of the armature. If any adjustment required gently tap the baseplate with a soft mallet until full contact is achieved. Mark the 2 baseplate corner locations lightly with a pencil for reference. Remove the lock from the baseplate and tighten both adjustment screws. Drive the remaining 4 screws into the header using the baseplate as a physical template. Screw heads must not project above the baseplate.




3. Attaching the lock to the baseplate

Using the Hex wrench, permanently fasten the lock to the baseplate with the two 1/4"-20 x 1 1/4" machine screws removed in step 1.



EXPLODED PARTS VIEW



**ARMATURE
ASSEMBLY
(TYPICAL)**

LEGEND ON NEXT PAGE



705 Emmett Street • Bristol, CT 06010
 1-877-DynaLock • www.dynalock.com

**MODEL 2050 SINGLE OUTSWING
 ELECTROMAGNETIC LOCK**

INSTALLATION INSTRUCTIONS

PARTS LEGEND

ITEM	DESCRIPTION	PART #
1	MOUNTING BASEPLATE	301495
2	#10 x 1" SELF TAPPING SCREW	*****
3	HOUSING	301496
4	ACCESS COVER	301497
5	8-32 x 3/8" MACHINE SCREW	*****
6	LOCK MOUNTING BOLT	300603
7	5/16"-18 x 2" ARM. SCREW TURNED	*****
8	ARMATURE	300968
9	ARMATURE HOUSING	301333`
10	ARMATURE SPACER	*****
11	ZINC WASHER	*****
12	DOOR SPACER	*****
13	SEX NUT	*****



705 Emmett Street • Bristol, CT 06010
1-877-DynaLock • www.dynalock.com

**MODEL 2050 SINGLE OUTSWING
ELECTROMAGNETIC LOCK**

INSTALLATION INSTRUCTIONS

**PLEASE DELIVER THIS MANUAL
TO THE END-USER UPON COMPLETION
OF THE INSTALLATION**

**FOR PRODUCT SUPPORT AND PARTS
ORDERING INFORMATION CONTACT:**

DynaLock Corp.
705 Emmett Street
Bristol, CT 06010
Bus: (877) 396-2562 Toll-Free
(860) 582-4761
Fax: (860) 585-0338

DYNALOCK ON THE INTERNET:

E-mail: info@dynalock.com
Website: www.dynalock.com




NYC Mea #23-92-E

GWXT Auxiliary Lock

PLEASE READ BEFORE ATTEMPTING INSTALLATIONS
3000/ 3000LC/ 2000/2050/2280 SERIES
CIRCUIT BOARD DESCRIPTION
 Refer to Page 2 & 3 for wiring instructions

The Coil Connector is not polarized and may go on in either direction.



WIRING INSTRUCTIONS

FIG. A

3000/2000/2280
12/24 VDC INPUT




FIG. B

3000/2000/2280
12/24 VAC INPUT





FIG. C


DYNASTAT OPTION



NOTES: 1. DYNASTAT CONTACTS RATED 1A MAXIMUM
2. INDICATORS NOT INCLUDED

FIG. D


DSM OPTION



NOTES: 1. DSM CONTACTS RATED 0.25A MAXIMUM
2. INDICATORS NOT INCLUDED

FIG. E

ANT-TAMPER (ATS) OPTION



ANTI-TAMPER OPTION INDICATES REMOVAL OF ACCESS COVER. THIS SWITCH IS LOCATED ON THE PRINTED CIRCUIT BOARD.



DRY CONTACT RATING 3A @ 30VDC/125VAC

ELECTRICAL SPECIFICATIONS

OPERATING VOLTAGES

12 OR 24 VAC / VDC


CURRENT CONSUMPTION, ALL MODELS

12 VAC / VDC - 0.44 A

24 VAC / VDC - 0.22 A

COIL RESISTANCE CHECK

REMOVE THE
MAGNET COIL
CONNECTOR
FROM THE
CIRCUIT BOARD TO
PERFORM THE COIL TEST



PROPER COIL RESISTANCE SHOULD BE
FROM POINTS 1 TO 3, ~ 53 OHMS
FROM POINTS 2 TO 4, ~ 53 OHMS

TROUBLESHOOTING TIPS

SYMPTOM	POSSIBLE CAUSE	CHECK FOR
DOOR WILL NOT LOCK OR NO MAGNETIC HOLDING FORCE	<ul style="list-style-type: none"> ● NO INPUT POWER ● AN OPEN CIRCUIT IN THE COIL 	<ul style="list-style-type: none"> <input type="checkbox"/> CHECK ALL CONNECTIONS. CHECK FOR VOLTAGE AT POWER SOURCE AND LOCK TERMINAL STRIP. <input type="checkbox"/> PERFORM THE COIL RESISTANCE CHECK. REFER TO BOTTOM OF THE PAGE 3.
LOW HOLDING FORCE	<ul style="list-style-type: none"> ● ARMATURE MOUNTING TOO RIGID ● INSUFFICIENT SUPPLY VOLTAGE 	<ul style="list-style-type: none"> <input type="checkbox"/> CHECK ARMATURE MOUNTING FOR FREE PIVOTING AND FULL CONTACT BETWEEN THE MATING SURFACE OF THE LOCK AND ARMATURE. <input type="checkbox"/> CHECK SUPPLY FOR PROPER INPUT VOLTAGE, SHOULD BE WITHIN 10%
MAGNET OVERHEATS AND / OR DRAWS EXCESS CURRENT	<ul style="list-style-type: none"> ● POSSIBLE SHORTED COIL 	<ul style="list-style-type: none"> <input type="checkbox"/> PERFORM THE COIL RESISTANCE CHECK. REFER TO BOTTOM OF PAGE 3.
DYNASTAT BOND SENSOR NOT INDICATING DOOR SECURE WHEN CLOSED AND LOCKED (WHEN APPLICABLE)	<ul style="list-style-type: none"> ● MAGNET AND / OR ARMATURE FACE DIRTY OR BURRED ● POOR LOCK / ARMATURE ALIGNMENT 	<ul style="list-style-type: none"> <input type="checkbox"/> CLEAN BOTH SURFACES WITH SCOTCH BRITE TYPE CLOTH AND APPLY WD-40. CHECK FOR BURRS. <input type="checkbox"/> CORRECT AS NECESSARY
DSM (DOOR STATUS MONITOR) NOT INDICATING DOOR CLOSED / OPEN STATUS (WHEN APPLICABLE)	<ul style="list-style-type: none"> ● DSM MAGNETS NOT INSTALLED IN ARMATURE HOUSING ● POOR LOCK / ARMATURE ALIGNMENT 	<ul style="list-style-type: none"> <input type="checkbox"/> REPLACE / INSTALL AS NECESSARY <input type="checkbox"/> CORRECT AS NECESSARY

Notes:

1. This lock may accept any one of 4 different input voltages and be furnished with a combination of options. Refer to page 1 for option location and pages 2 and 3, figure A thru E, for wiring instructions that apply to your specific installation.
2. For additional system wiring information, refer to the installation documentation furnished with the external hardware and / or peripheral devices (I.E. power supply, station controls, keypad, card readers, etc.) supplied by DynaLock and / or others.

**PLEASE DELIVER THIS MANUAL
TO THE END-USER UPON COMPLETION
OF THE INSTALLATION**

**FOR PRODUCT SUPPORT AND PARTS
ORDERING INFORMATION CONTACT:**

DynaLock Corp.
705 Emmett Street
Bristol, CT 06010
Bus: (877) DYNALOCK, Toll-Free USA
(860) 582-4761
Fax: (860) 585-0338

DYNALOCK ON THE INTERNET:

E-mail: info@dynalock.com
Website: www.dynalock.com