

INSTALLATION DIRECTIONS

BEFORE APPLYING THIS DEVICE

- ## 1. APPLY STRIKE

- ## 2. PREPARE DOOR

- ### 3. APPLY OUTSIDE TRIM

- B. Prepare outside face of lock stile.

- D. Apply outside trim.**

4. INSTALL LEVER ARMS

- ## 5. APPLY LOCK STILE CASE

- A. Remove key from cylinder.

- B. Position cylinder cam as shown in Fig. 3.

- C. Attach lock stile case to door. (See Fig. 1 or Fig. 2)

- #### 6. APPLY HINGE STILE CASE AND CROSSBAR TUBE (FIG. 4)

- A. Slip crossbar tube on lock stile and hinge stile lever arms. (See Direction No. 941009 for cutting crossbar, if necessary.)

- B. Be sure crossbar is level and hinge stile case is parallel to edge of door and approximately on centerline of exposed stile.

- C. Using holes in hinge stile case, mark location and prepare door for attaching screws.

- D. Apply hinge stile case with crossbar in place.**

- E. Tighten wedge-tite set screws securely with dog key and screwdriver or equivalent for leverage, and test crossbar for free action. (See Direction No. 941009 for these instructions.)



**SINGLE DOOR OPENING
39-13/16 TO FINISHED FLOOR**

**FOR TRIM APPLICATION SEE DIRECTIONS
IN TRIM CARTON**




Customer Service

1-877-671-7011 www.allegion.com/us


VON DUPRIN®

| | | |
|---------------------|--------------|--------------------|
| DIRECTION NUMBER | 911172-00(b) | DATE Rev. 01/14 |
|---------------------|--------------|--------------------|



TEMPLATE NO. 1

TEMPLATE NO. 2



LHR SHOWN
RHR OPPOSITE



941104-00

Control for 88 Rim Device on Metal or Wood Door


373-L, 373-L-BE

VON DUPRIN®

Installation Instructions

INSTALLATION INSTRUCTIONS

1. Prepare door for exit device. See exit device instructions for locations of holes, backset (line X-X), and center lines.
2. Prepare door for control:
 - a. Transfer line X-X from inside (exit device side) of door to outside (control side) of door. Use extra care if edge of door is beveled. Be sure line X-X is parallel to edge of door.
- ① **Note: See back side of sheet for hole preparation for metal or wood.**
 - b. Locate and prepare holes as indicated.
3. Install cylinder into control if required (Figures 1 & 2). Insure cylinder cam is set for required function and replace if necessary.
- ① **Note: Exit device must be in unlocked position before installation.**
4. Install control and exit device to door.
5. Test key, control, and device action.



TL Function - Control remains unlocked when key is removed.

NL Function - Control relocks when key is removed. Requires use of key to operate.

For NL function replace TL cylinder plate (std. on all controls) with NL cylinder plate (included in polybag) replacing screw and washer.

Note: Control must be in locked position when installing cylinder plate.

Figure 1





Figure 2



For cutouts on inside face of door see instructions in device carton.

| Device Application Schedule | |
|-----------------------------|---------------|
| Device | Dimension "A" |
| 88K Rim | 5" |

Customer Service

1-877-671-7011 www.allegion.com/us

